

WellSafe Systems

WellSafe Enabler

- ✓ Protects against overload on Workover riser
- ✓ Can be turned on and off
- ✓ Strong mode during rig up and landing
- ✓ Weak mode in “locked to bottom”
- ✓ Adjustable weak mode setting point
- ✓ Activates on over-tension and loss of tension

