

WellSafe Systems

WellSafe Installer

- ✓ Applicable for TH Installation and X-mas tree Installation
- ✓ Integrated part of drillstring
- ✓ Strong mode during running
- ✓ Weak mode in “locked to bottom”
- ✓ Adjustable weak mode setting point
- ✓ Can be turned ON and OFF

